


Harness Instructions

The regulator hose slides through the D Ring and attaches to the check valve on the back of the harness



It is important to keep Quick Release Buckle located directly in front of you. This way you can easily locate the Quick Release Buckle in case of an emergency. This also forces the shoulder strap to cross your chest and keep the shoulder strap from falling off your shoulder.



Shoulder strap loops around waist strap. Adjust loop so that it cannot slide over the Quick Release Buckle and still is able to slide of the waist strap in case of an emergency



The regulator hose slides through the D Ring and attaches to the check valve on back plate.

Back Plate & Check Valve

Be sure to take the time to get the harness adjusted correctly with the wet suit on. If you have excess strap left over be sure to cut it and seal the edges with heat.